


## Specification Sheet

Software > Pro Workflow



### Custom controls for your touchscreen project

With an intuitive drag-and-drop interface, Dynalite UI Creator (the "Software Services"), empowers commissioning engineers to easily build screens and menus with the required functions, controls, and branding for any project.

Customise any page with buttons, sliders, text, graphic elements, and more to provide users with a seamless experience of the Dynalite system.

## Key Features

---

- **Quick Start Wizard** - Import project data from Dynalite System Builder to create a full-featured control UI with just a few mouse clicks.
- **Intuitive drag-and-drop interface** - Add and arrange controls, text elements, images, indicators, and more.
- **Simple configuration menus** - Customise the appearance and functionality of any page, element, or control with ease.
- **Access control** - PIN code logins protect your touchscreen from unauthorised access when located in a public area.
- **Images and backgrounds** - Add full-colour branding and logos, decorative elements, or even helpful instructions for new users.
- **Time and date** - Show the current time and/or date on any page with adjustable fonts, sizes, and colors.
- **Buttons** - Recall scenes, navigate between pages, and trigger advanced tasking functions within the PDTS. You can even place invisible buttons over a background floor plan for intuitive navigation to each room or area page.
- **Sliders** - Adjust light and tuneable white levels for individual lighting groups.
- **Status indicators** - Provide at-a-glance confirmation of active presets in any area.
- **Environmental indicators and controls** - Add temperature and humidity readouts, with optional HVAC controls to adjust the temperature setpoint.

## Compatibility

Dynalite UI Creator is designed to work exclusively with the Dynalite PDTS Touchscreen.

## Operating Environment

---

Dynalite UI Creator is an application installed locally on your Windows-based desktop or laptop. The following requirements are needed on your machine to support the Software Services:

Software Requirements		Hardware Requirements	
Operating System	Windows 10/11 (x64)	Platform	Intel / AMD 64-Bit
		CPU	≥ 2.5 GHz, 2+ cores
		RAM	≥ 4 GB
		Storage	≥ 10 GB available
		Display Resolution (Minimum)	1024x768
		Display Resolution (Recommended)	≥ 1920x1080

## Hardware Note

---

- Minimum requirements may vary depending on project size.

## Ordering

---

Dynalite UI Creator can be downloaded for free from [support.dynalite.com](https://support.dynalite.com), or via your Dynalite partner or Signify representative.

## Policies and Notices

---

### Security

The Software Services are covered by the Signify Security Statement, which is available at [signify.com/global/product-security/professional-systems-and-services](https://signify.com/global/product-security/professional-systems-and-services).

A product-specific security statement may be available on request at Signify's discretion and subject to confidentiality conditions.

### Usage Restrictions

The Software Services should not be used for any purpose other than stated in this specification sheet.

The Software Services and any data generated or processed thereby must not be used or relied upon for applications or activities where the use or failure of the Software Services could lead to death, personal injury, or environmental damage.

### Applicable Terms and Conditions

The access and use of these Software Services are subject to our most recent Terms of Software Services as published at: [Terms of Software Services](#)

### Data

If we process personal data, we will do so in accordance with our [Data Processing Agreement and applicable data processing schedule\(s\)](#) or [Privacy Notice](#), as applicable to our role in that processing.

### Software End of Life Policy

The Software Services are subject to Signify's End of Life policy that can be found here: [Policies & Announcements](#)

### Open Source Software

An overview of included open source software is available in the Software Services' **File > About > Licenses** section.

### Update / Upgrade

Signify Dynalite may release updated and/or upgraded versions of the Software Services from time to time, at its discretion. For any such update or upgrade, the main changes are indicated in the release notes. Changes may not be reflected in an update of this document.

### Disclaimer

This Software Specification represents the current specification of the Software Services as of the date of publication of this document but is provided 'as is' without warranty of any kind, whether express or implied. This information is subject to change without notice. Customers are responsible for making their own independent assessment of the Software Services and the use thereof. Any commitments or liabilities in respect hereof are exclusively defined in the agreements between Signify Dynalite and its customers.

More detailed information about the Software may be available on request but at Signify's discretion.