


Technical Requirements

Dynalite environment	Partner environment
PDTS with internet connectivity. System Builder: PDTS configured as an Ethernet to RS-485 Translation Gateway. All devices placed under the PDTS (No Logical or Physical Address Range Offsets allowed). Matter enabled in Device properties.	Matter hub with internet connectivity Smart home platform app
UI Creator: an 'Open settings menu' page with matter on the PDTS to select the Matter QR code page.	Identify and name Dynalite Matter accessories in the app
System Builder: upload UI Creator pages and Project.xml file to the PDTS (Limit of 128 Dynalite Matter accessories)	
Versions PDTS v2. Firmware: 4.09 or higher SB: 5.49 or higher UI Creator: 3.1.8 or higher	

Dataflow Diagram



Contact Details

Dynalite
 15B Cargo Place, Moorebank NSW 2170, Australia
 Ph: +61 2 8338 9899
 Email: support.controls@signify.com